

# Digital Pocket Scale

## User Manual

*Thank you for purchasing our pocket scale.*

*Please read all operating instructions carefully before use.*

- This electronic scale is a precision instrument. With normal care and proper treatment, it will provide years of reliable service.
- Never load the scale with more than the maximal capacity. Overloading can permanently damage it!
- Avoiding any exposure to extreme heat or cold, your scale works better when operated at normal room temperature. Always allow the scale to acclimate to normal room temperature for at least 1 hour before use.
- Give your scale sufficient warm up time. Usually 30 seconds to give the internal components a chance to stabilize before calibration.
- Keep your scale in a clean environment. Dust, dirt, moisture, vibration, air currents and a close distance to other electronic equipment can all cause an adverse effect on the reliability and accuracy of your scale.
- Handle with care. Gently apply all items to be weighed onto tray top. Although this scale is designed to be quite durable, try to avoid rough treatment as this may permanently damage the internal sensor.
- Avoid shaking, dropping or otherwise shocking the scale. This is a precision instrument and must be handled with extreme care.
- Only operate the scale on a stable, vibration free surface.

### OPERATION:

1. Place scale on a horizontal flat surface, press [ON/OFF] key to turn on the scale.
2. Wait until "0.00" is displayed.
3. Put the object(s) on the weighing platform.
4. Using the [MODE] key, you can switch between the weighing units.

### TARE WEIGHING

1. Turn on scale as described above.
2. Place the "tare item" on the platform.
3. Press [TARE] and wait until "0.00" is displayed.
4. Add the "net-weight-item".

**Calibration is not required before first use. Only calibrate if the scale is not weighing properly.**

1. Turn on the scale by press [ON/OFF] key.
2. Hold [MODE] key for a few seconds, display will show "CAL". Press [MODE] key again, then it will show a certain weight.
3. Place the required calibration weight onto the platform and wait for 5 seconds.
4. The display will show "PASS" then return to normal weighing mode.
5. Put away the calibration weight and press [ON/OFF] to turn off the scale and the calibration is finished.

### SPECIFICATION:

Calibration: Auto calibration

Weighing mode: g oz gn ct ozt dwt tl

Operation temp: 50-86 degrees Fahrenheit

Power: 2 x AAA Batteries